

Programming Your Thermostat

The chart on the right shows the factory settings for this thermostat. If these settings work with your lifestyle, simply push the “RUN” (5) button.

Program your own settings using the blank chart on the back of this reference guide to set the thermostat to your own time and temperature preferences.

Period		WEEKDAYS		SATURDAY		SUNDAY	
		Start Time	Temp	Start Time	Temp	Start Time	Temp
HEAT	Morning	6 AM	70° F	6 AM	70° F	6 AM	70° F
	Day	8 AM	65° F	8 AM	65° F	8 AM	65° F
	Evening	5 PM	70° F	5 PM	70° F	5 PM	70° F
	Night	10 PM	68° F	10 PM	68° F	10 PM	68° F
COOL	Morning	6 AM	76° F	6 AM	76° F	6 AM	76° F
	Day	8 AM	78° F	8 AM	78° F	8 AM	78° F
	Evening	5 PM	74° F	5 PM	74° F	5 PM	74° F
	Night	10 PM	76° F	10 PM	76° F	10 PM	76° F

Thermostat Time Periods

Program your thermostat with your household schedule in mind. The first time period, “MORNING,” may be the time you typically wake up. “DAY” could be the time you leave the house; therefore, you would want to use a temperature setting that will save you energy while you are away. “EVENING” may be the time you return at the end of the day, while “NIGHT” may be the time you go to bed – another good time to save energy. You may set different schedules for weekdays, weekends and holidays. You can change these times and settings any way you like or even use the same setting most of the time to suit your lifestyle.

STEP 1: Set the Time and Day

Press the “TIME” (3) button once. The hour will appear. Press the up or down arrow until you reach the desired hour. Press “TIME” again. Set the minutes and AM/PM setting in the same manner. Press “TIME” again to set the day of the week. Press the “RUN” (5) button once.

STEP 2: Set the Heating Program Schedule


1. Press and hold the “SYSTEM” (8) button until the word “HEAT” is displayed.
2. Press the “PROGRAM” (4) button. The letters “MOR” will appear in the upper left corner. The temperature setting should blink. Use the up or down arrow to change the temperature to setting you wrote on your chart.
3. Press “TIME” (3) to set the begin time for this period. Use the up or down arrow to set the time. When you press “PROGRAM” again, you will move to the second time period on your chart. Repeat steps 2 and 3 within this section until you have programmed all of the times and temperatures for the settings on your chart.
4. Press the “RUN” (5) button; the thermostat will run the program you have set.

STEP 3: Set the Cooling Program Schedule

1. Press the “SYSTEM” (8) button until the word “COOL” is displayed.
2. Press the “PROGRAM” (4) button. Set the temperature and time exactly as you did for programming the heating schedule above.

If you make a mistake, press the “RUN” (5) button to start over. Press “PROGRAM” (4) to go from one program to the next.

- (1) Up Arrow
- (2) Down Arrow
- (3) Set Time
- (4) Program – To program a heating or cooling schedule
- (5) Run – To run the pre-programmed heating or cooling schedule
- (6) Hold – To hold the temperature
- (7) Fan – Selects “auto” fan or fan on continuously
- (8) System – Changes between heating, cooling, heating/cooling and emergency heat for heat pumps



Demand Conservation Program Thermostat – Quick Reference

To Operate Your Thermostat

Press and hold the “SYSTEM” (8) button until your choice of “COOL,” “HEAT” or “OFF” appears in the middle of the display. “COOL” or “HEAT” are good choices in the middle of the season. Another choice, which reads, “HEAT/COOL” on the display, combines your heating and cooling settings to maintain a specific temperature. The thermostat will automatically switch from cooling to heating in order to maintain a comfortable setting. This is a good choice when the weather is unpredictable.

NOTE: When “HEAT/COOL” is selected, the “HEAT” setting for every programming time must be at least three degrees below the “COOL” setting in order to prevent cycling back and forth from heat to cool.

Time and Temperature

If you set the thermostat for 70 degrees at 8 a.m., the thermostat automatically calculates how much time it needs to start heating or cooling **before** 8 a.m. so that the inside air temperature will be at 70 degrees by 8 a.m.

Temporarily Change the Temperature

Use the up or down arrow buttons on the right side of the display until the desired temperature is selected. The thermostat will hold the temperature until your next programmed time period.

Release a Temperature Hold

Press the “RUN” (5) button.

Changing the Batteries

With the bottom hinged door closed, gently pull the bottom edge of the thermostat to remove the outer casing from the thermostat. This will reveal the two AA batteries, which should be changed annually.

WHO TO CALL FOR HELP

Call the LG&E/KU Demand Conservation Program toll free at 1-800-356-5467 or visit our Web site at www.eon-us.com/dc for a complete user’s programming guide.

	Period	WEEKDAYS		SATURDAY		SUNDAY	
		Start Time	Temp	Start Time	Temp	Start Time	Temp
HEAT	Morning						
	Day						
	Evening						
	Night						
COOL	Morning						
	Day						
	Evening						
	Night						